

Programming Guide

Advanced 2D Image Scanner

This Programming Guide is intended for:

- 2D Image On-Counter Scanner: Z-8082 Lite

Revision History

Changes to the original manual are listed below:

Version	Date	Description of Version
1.0.1	2019/1/2	Initial Release
1.0.2	2019/1/21	Add Stand By Mode Setting Same Code Delay Setting

Important Notice

No warranty of any kind is made in regard to this material, including, but not limited to, implied warranties of merchantability or fitness for any particular purpose. We are not liable for any errors contained herein nor for incidental or consequential damages in connection with furnishing, performance or use of this material. We shall be under no liability in respect of any defect arising from fair wear and tear, willful damage, negligence, abnormal working conditions, failure to follow the instructions and warnings, or misuse or alteration or repair of the products without written approval. No part of this document may be reproduced, transmitted, stored in a retrieval system, transcribed, or translated into any human or computer or other language in any form or by any means electronic, mechanical, magnetic, optical, chemical, biological, manual or otherwise, except for brief passages which may be quoted for purposes of scholastic or literary review, without express written consent and authorization. We reserve the right to make changes in product design without reservation and without notification. The material in this guide is for information only and is subject to change without notice. All trademarks mentioned herein, registered or otherwise, are the properties of their various, ill, assorted owners.

General Handling Precautions

- Do not dispose the scanner in fire.
- Do not put the scanner directly in the sun or by any heat source.
- Do not use or store the scanner in a very humid place.
- Do not drop the scanner or allow it to collide violently with other objects.
- Do not take the scanner apart without authorization

Guidance for Printing

This manual is in A5 size. Please double check your printer setting before printing it out. When the barcodes are to be printed out for programming, the use of a high-resolution laser printer is strongly suggested for the best scan result.

Firmware Notice

To use all functions in this guide please update to the latest firmware.

Copyright © 2018 ZEBEX INDUSTRIES INC. All rights reserved.

Table of Contents

Important Notice.....	ii
General Handling Precautions.....	ii
Guidance for Printing	ii
Using the Scanner	1
Beeper Indication.....	1
LED Indication	1
Settings and Programming.....	2
Program Set Up Flow.....	2
User Preferences	3
Show Version.....	3
System Settings	3
Interface Switch.....	4
Terminal Character	5
RS232 Baud Rate	6
Standby Mode Timeout	8
Sleep Mode Timeout.....	10
Same Code Delay Time	12
Symbology Parameter Defaults.....	13
Symbology Default Table.....	13
Readable Symbologies	14
All Symbologies	14
UPC-A	15
UPC-E.....	16
EAN 8.....	17
EAN 13.....	18
Code 128	19
Code 39	20
Code 93	21
Codabar	22
Plessey.....	23
MSI Plessey.....	24
Interleaved 2 of 5	25
PDF 417	26
Micro PDF 417	27
DataMatrix	28
QR Code	29
Micro QR Code	30
Symbology Features	31
UPC / EAN.....	31
UPC-A	32

UPC-E.....	34
EAN 8.....	36
EAN 13.....	37
Code 39.....	39
Codabar.....	41
Interleaved 2 of 5.....	43
MSI Plessey.....	44
DataMatrix.....	46
QR / Micro QR.....	48
Data Editing (Prefix).....	50
Prefix Set Up Flow.....	50
All Prefix.....	51
UPC / EAN Prefix.....	52
Code 128 Prefix.....	54
Code 39 Prefix.....	55
Code 93 Prefix.....	56
Codabar Prefix.....	57
Plessey Prefix.....	58
MSI Plessey Prefix.....	59
Interleaved 2 of 5 Prefix.....	60
PDF 417 Prefix.....	61
Micro PDF 417 Prefix.....	62
DataMatrix Prefix.....	63
QR Code Prefix.....	64
Micro QR Code Prefix.....	65
Data Editing (Suffix).....	66
Suffix Set Up Flow.....	66
All Suffix.....	67
UPC-A Suffix.....	68
UPC-E Suffix.....	69
EAN 8 Suffix.....	70
EAN 13 Suffix.....	71
Code 128 Suffix.....	72
Code 39 Suffix.....	73
Code 93 Suffix.....	74
Codabar Suffix.....	75
Plessey Suffix.....	76
MSI Plessey Suffix.....	77
Interleaved 2 of 5 Suffix.....	78
PDF 417 Suffix.....	79
Micro PDF 417 Suffix.....	80
DataMatrix Suffix.....	81

QR Code Suffix.....	82
Micro QR Code Suffix	83
Code Settings	84
Set Lengths for Codes.....	84
Set Lengths for Code 128	86
Set Lengths for Code 39	87
Set Lengths for Code 93	88
Set Lengths for Codabar	89
Set Lengths for Interleaved 2 of 5	90
Set Lengths for MSI Plessey.....	91
Code Identifiers	92
Code Identifiers Table.....	93
Keyboard Caps Lock State	94
Function Key Mapping	95
ASCII Code	96
USB Virtual COM Driver Installing.....	118

Using the Scanner

Beeper Indication

Beeps	Indication
1 short beep	A barcode has been successfully decoded
2 short beeps	The scanner has entered program mode
1 long beep	A setting has been programmed
3 beeps in a series from low to high pitch	The scanner has exited program mode
3 short beeps	Error setting the scanner

LED Indication

Beeps	Indication
Steady Blue	Scanner in work mode
1 Red Flash	A barcode has been successfully decoded

Settings and Programming

Scan selected barcodes in this manual to affect setup and programming of your 2D image barcode scanner. Decoding options and interface protocols can be tailored to a specific application.

Setup parameters are stored in non-volatile memory in the scanner and are retained even when power is off. Setup parameters change only when you reset them. You may need to hide adjacent code patches with your hand when scanning.

Program Set Up Flow

Scan "**Set**" to set up -> Scan selected barcode -> Scan "**End**" to confirm the setup.

User Preferences

Show Version


Scan this barcode to display firmware version.



Read device information

System Settings


Scan this barcode to return all parameters to the default values.



Set




Factory default settings




End

Interface Switch


Your 2D Imager supports interfaces such as USB HID, RS232 serial, and USB virtual COM. To switch the interface, simply select the appropriate cable and configure the proper interface by following interface selection.




Set




RS-232



USB Keyboard




USB Virtual COM Port
*Driver required




End


Terminal Character




Set




None



CR (Default)




TAB




End

RS232 Baud Rate


Baud rate is the number of bits of data transmitted per second. Set the imager's baud rate to match the baud rate setting of the host device. Otherwise, data may not reach the host device or may reach it in distorted form.




Set




9600




19200




38400




57600




End




Set



115200 (Default)




230400




End

Standby Mode Timeout


Use the barcodes below to set the timeout to standby Mode. When entering Standby Mode, the LED illumination would reduce brightness.




Set




Off (Default)




20 seconds




30 seconds



End




Set




1 minute



5 minutes



10 minutes




End


Sleep Mode Timeout

Use the barcodes below to set the timeout to Sleep Mode. When entering Sleep Mode, the LED illumination would turn off.

Before using this mode, please **turn off** Standby Mode.




Set




Off (Default)




30 seconds




1 minutes




End




Set




5 minutes



10 minutes




30 minutes




End

Same Code Delay Time


Scan a barcode below to select the duration of the same code delay time.



Set




200 msec




500 msec (Default)



1 second



2 seconds



End

Symbology Parameter Defaults

Table below lists the defaults for all symbologies parameters. To change any option, scan the appropriate barcode(s) provided in the Readable Symbologies section.


Symbology Default Table

Symbology	Default
UPC-A	Enable
UPC-E	Enable
EAN 8	Enable
EAN 13	Enable
Code 128	Enable
Code 39	Enable
Code 93	Enable
Codabar	Enable
Plessey	Disable
MSI Plessey	Enable
Interleaved 2 of 5	Enable
PDF417	Enable
Micro PDF417	Disable
Data Matrix	Enable
QR	Enable
Micro QR	Disable

Readable Symbolologies

This section provides the programming barcodes for enabling and disabling readable symbolologies. If the default values suit requirements, programming is not necessary.

All Symbolologies




Set




Enable All Symbolologies




Enable 1D Symbolologies Only



Enable 2D Symbolologies Only



End

UPC-A


Set



Enable UPC-A (Default)




Disable UPC-A



End


UPC-E




Set




Enable UPC-E (Default)



Disable UPC-E




End

EAN 8


Set



Enable EAN 8 (Default)




Disable EAN 8



End

EAN 13




Set




Enable EAN 13 (Default)



Disable EAN 13




End

Code 128


Set



Enable Code 128 (Default)




Disable Code 128



End


Code 39




Set




Enable Code 39 (Default)



Disable Code 39




End

Code 93


Set



Enable Code 93 (Default)




Disable Code 93



End

Codabar




Set



Enable Codabar (Default)




Disable Codabar



End

Plessey




Set



Enable Plessey




Disable Plessey (Default)



End

MSI Plessy




Set



Enable MSI Plessy (Default)




Disable MSI Plessy



End

Interleaved 2 of 5




Set



Enable Interleaved 2 of 5 (Default)




Disable Interleaved 2 of 5



End

PDF 417




Set




Enable PDF 417 (Default)



Disable PDF 417



End

Micro PDF 417


Set



Enable Micro PDF 417 (Default)




Disable Micro PDF 417



End


DataMatrix




Set



Enable DataMatrix (Default)




Disable DataMatrix




End

QR Code




Set



Enable QR Code (Default)




Disable QR Code




End


Micro QR Code




Set



Enable Micro QR Code



Disable Micro QR Code (Default)




End

Symbology Features

This section provides the programming barcodes for selecting features available to different symbologies.

UPC / EAN




Set



Enable decoding of 2/5-digit supplemental code for UPC-A, UPC-E, EAN 13, and EAN 8




Disable decoding of 2/5-digit supplemental code for UPC-A, UPC-E, EAN 13, and EAN 8 (Default)




End


UPC-A




Set




Enable UPC-A Number System digit
(Default)




Disable UPC-A Number System digit




Enable UPC-A check digit (Default)




Disable UPC-A check digit




End




Set



Enable conversion of UPC-A to EAN 13




Disable conversion of UPC-A to EAN 13
(Default)




End


UPC-E




Set




Enable UPC-E number system digit
(Default)




Disable UPC-E number system digit




Enable UPC-E check digit (Default)




Disable UPC-E check digit




End




Set



Enable conversion of UPC-E to UPC-A




Disable conversion of UPC-E to UPC-A
(Default)




End


EAN 8




Set




Enable EAN 8 check digit (Default)




Disable EAN 8 check digit




Enable conversion of EAN 8 to EAN 13




Disable conversion of EAN 8 to EAN 13
(Default)




End

EAN 13


Set





Enable EAN 13 check digit (Default)




Disable EAN 13 check digit




Enable conversion of EAN 13 to ISBN

Disable conversion of EAN 13 to ISBN
(Default)


End




Set




Enable conversion of EAN 13 to ISSN




Disable conversion of EAN 13 to ISSN
(Default)




End

Code 39


Set




Enable Code 39 full ASCII mode




Disable Code 39 full ASCII mode (Default)




Enable start and stop characters




Disable start and stop characters (Default)




End




Set




Disable checksum (Default)




Enable checksum and send check character




Enable checksum and strip check character




End

Codabar


Set




Disable checksum (Default)




Enable checksum and send check character




Enable checksum and strip check character




End




Set




Enable stripping start and stop characters




Disable stripping start and stop characters
(Default)




End

Interleaved 2 of 5


Set




Disable checksum (Default)



Enable checksum and send check character




Enable checksum and strip check character




End


MSI Plessey




Set




Disable MSI Plessey checksum



Mod 10 checksum (Default)




Mod 10/10 checksum




Mod 11/10 checksum




End




Set



Output checksum character(s) (Default)




Strip checksum character(s)




End


DataMatrix




Set




Enable mirror decoding (Default)



Disable mirror decoding



End




Set



Enable rectangular DataMatrix decoding
(Default)




Disable rectangular DataMatrix decoding




End


QR / Micro QR




Set




Enable mirror decoding (Default)





Disable mirror decoding




End



Set

Universal Simple Chinese output for
Notepad, ExcelUniversal multi-language output for
Notepad, Excel (Default)

Code-page output for Word



End

Data Editing (Prefix)


Prefix is additional characters that can be sent before the scanned data. Please scan the barcodes in the selection below to set your prefix.

Prefix Set Up Flow


1. Scan Set.
2. Enable barcode type.
3. Scan prefix you would like to add characters within ASCII Table. Up to 4 digits can be added.
4. Scan End.

Ex. If we wish to add "3" as prefix for all barcode type, then follow procedure as below, Scan [Set] to enter setup. Then we select barcode by scanning [Enable All], then we scan [3] as 3 of ASCII HEX. At the end, we scan [End] to completed setup.


All Prefix




Set



Enable All




Disable All (Default)




End


UPC / EAN Prefix




Set




Enable UPC-A




Disable UPC-A




Enable UPC-E




Disable UPC-E




End




Set




Enable EAN 8




Disable EAN 8



Enable EAN 13




Disable EAN 13




End


Code 128 Prefix




Set



Enable Code 128




Disable Code 128




End


Code 39 Prefix




Set



Enable Code 39




Disable Code 39




End


Code 93 Prefix




Set



Enable Code 93




Disable Code 93




End


Codabar Prefix




Set



Enable Codabar




Disable Codabar




End


Plessey Prefix




Set



Enable Plessey




Disable Plessey




End


MSI Plessey Prefix




Set



Enable MSI Plessey




Disable MSI Plessey




End


Interleaved 2 of 5 Prefix




Set




Enable Interleaved 2 of 5




Disable Interleaved 2 of 5




End

PDF 417 Prefix


Set



Enable PDF 417




Disable PDF 417




End


Micro PDF 417 Prefix




Set



Enable Micro PDF 417




Disable Micro PDF 417




End


DataMatrix Prefix




Set



Enable DataMatrix




Disable DataMatrix




End


QR Code Prefix




Set



Enable QR Code




Disable QR Code




End


Micro QR Code Prefix




Set



Enable Micro QR Code



Disable Micro QR Code



End

Data Editing (Suffix)


Suffix is additional characters that can be sent after the scanned data. Please scan the barcodes in the selection below to set your suffix.

Suffix Set Up Flow


1. Scan Set.
2. Enable barcode type.
3. Scan suffix you would like to add characters within ASCII Table. Up to 4 digits can be added.
4. Scan End.

Ex. If we wish to add "36" as suffix for all barcode type, then follow procedure as below. Scan [Set] to enter setup. Then we select barcode by scanning [Enable All], then we scan [3] as 3 of ASCII HEX and [6] as 6.


All Suffix




Set



Enable All




Disable All (Default)




End


UPC-A Suffix




Set



Enable UPC-A




Disable UPC-A




End


UPC-E Suffix




Set



Enable UPC-E




Disable UPC-E




End


EAN 8 Suffix




Set



Enable EAN 8




Disable EAN 8




End


EAN 13 Suffix




Set



Enable EAN 13




Disable EAN 13




End


Code 128 Suffix




Set



Enable Code 128




Disable Code 128




End


Code 39 Suffix




Set



Enable Code 39




Disable Code 39




End


Code 93 Suffix




Set



Enable Code 93




Disable Code 93




End


Codabar Suffix




Set



Enable Codabar




Disable Codabar




End


Plessey Suffix




Set



Enable Plessey




Disable Plessey




End


MSI Plessey Suffix




Set



Enable MSI Plessey




Disable MSI Plessey




End


Interleaved 2 of 5 Suffix




Set




Enable Interleaved 2 of 5




Disable Interleaved 2 of 5




End

PDF 417 Suffix


Set



Enable PDF 417




Disable PDF 417




End


Micro PDF 417 Suffix




Set



Enable Micro PDF 417




Disable Micro PDF 417




End


DataMatrix Suffix




Set



DataMatrix Enable




DataMatrix Disable




End


QR Code Suffix




Set



QR Code Enable




QR Code Disable




End


Micro QR Code Suffix




Set



Micro QR Code Enable



Micro QR Code Disable



End

Code Settings

Set Lengths for Codes

- One Discrete Length

Select this option to decode the symbol containing a selected length.
Select the length using the numeric bar codes in ASCII Code Table.

Example 1:

To decode Interleaved 2 of 5 symbols with 8 characters:

- scan Set to set up
- scan Interleaved 2 of 5 One Discrete Length
- scan 8 in ASCII Code Table
- scan End to confirm the setup

Example 2:

To decode Interleaved 2 of 5 symbols with 12 characters:

- scan Set to set up
- scan Interleaved 2 of 5 One Discrete Length
- scan scan 1 followed by 2 in ASCII Code Table
- scan End to confirm the setup

- Two Discrete Lengths

Select this option to decode the symbol containing either of two selected lengths.
Select lengths using the numeric bar codes in ASCII Code Table.

Example:

To decode Code 128 symbols containing either 8 or 14 characters

- scan Set to set up
- scan Code 128 Two Discrete Length
- scan 0, 8, 1, and then 4 in ASCII Code Table
- scan End to confirm the setup

- Length Within Range

Select this option to decode the symbol with a specific length range. Select lengths using numeric bar codes in ASCII Code Table.

Example:

To decode Codabar symbols containing between 7 and 8 characters,

- a. scan Set to set up
- b. scan Codabar Length Within Range
- c. scan 0, 7, 0, and then 8 in ASCII Code Table
- d. scan End to confirm the setup


- Any Length

Select this option to decode the symbol containing any number of characters within the digital scanner's capability.

Example:

- a. scan Set to set up
- b. scan Matrix 2 of 5 Any Length
- c. scan End to confirm the setup

Set Lengths for Code 128




Set



One Discrete Length




Two Discrete Lengths



Length Within Range




Any Length (Default)



End

Set Lengths for Code 39



Set



One Discrete Length




Two Discrete Lengths



Length Within Range




Any Length (Default)



End

Set Lengths for Code 93




Set



One Discrete Length




Two Discrete Lengths



Length Within Range




Any Length (Default)




End

Set Lengths for Codabar



Set



One Discrete Length




Two Discrete Lengths



Length Within Range




Any Length (Default)



End

Set Lengths for Interleaved 2 of 5




Set



One Discrete Length




Two Discrete Lengths



Length Within Range




Any Length (Default)




End


Set Lengths for MSI Plessey




Set



One Discrete Length




Two Discrete Lengths



Length Within Range




Any Length (Default)



End

Code Identifiers


Scan the following barcodes to set symbology Identifiers.




Set



Disable Code ID (Default)



Enable AIM ID




End

Code Identifiers Table

Symbology	AIM ID
UPC-A	E
UPC-E	E
EAN 8	E
EAN 13	E
Code 128	C
Code 39	A
Code 93	G
Codabar	F
Plessey	P
MSI Plessey	M
Interleaved 2 of 5	I
PDF417	L
Micro PDF417	L
Data Matrix	d
QR	Q
Micro QR	Q

Keyboard Caps Lock State

Scan a barcode below to turn Caps on or off.




Set



Caps Lock Off (Default)




Caps Lock On



End

Function Key Mapping

Scan the following barcodes to enable or disable Function Key Mapping.




Set



Disable Function Key Mapping (Default)




Enable Function Key Mapping




End

ASCII Code


For parameters requiring specific numeric values, scan the appropriately numbered barcode(s).




Space




!




"




#




\$




%




&




,




(




)




*




+




,




-




.




/




[




\




]




^




-




\




?




@




{




|




}




~




0




1




2




3




4




5




6




7



8




9




A

(Function Key
Mapping: Ctrl+a)




B


(Function Key
Mapping: Ctrl+b)




C
(Function Key
Mapping: Ctrl+c)




D
(Function Key
Mapping: Ctrl+d)




E
(Function Key
Mapping: Ctrl+e)



F
(Function Key
Mapping: Ctrl+f)




G
(Function Key
Mapping: Ctrl+g)




H

(Function Key
Mapping: Ctrl+h)




I

(Function Key
Mapping: Ctrl+i)




J

(Function Key
Mapping: Ctrl+j)




K

(Function Key
Mapping: Ctrl+k)




L


(Function Key
Mapping: Ctrl+l)




M
(Function Key
Mapping: Ctrl+m)




N
(Function Key
Mapping: Ctrl+n)




O
(Function Key
Mapping: Ctrl+o)



P
(Function Key
Mapping: Ctrl+p)




Q
(Function Key
Mapping: Ctrl+q)




R

(Function Key
Mapping: Ctrl+r)




S

(Function Key
Mapping: Ctrl+s)




T

(Function Key
Mapping: Ctrl+t)




U

(Function Key
Mapping: Ctrl+u)




V


(Function Key
Mapping: Ctrl+v)




W
(Function Key
Mapping: Ctrl+w)




X
(Function Key
Mapping: Ctrl+x)




Y
(Function Key
Mapping: Ctrl+y)




Z
(Function Key
Mapping: Ctrl+z)




a




b




c




d




e




f




g




h




i




j




k




l




m




n




o




p




q




r




s




t




u




v




w



x




y



z



Insert



Delete




Home



End



Up arrow



Down arrow



Left arrow



Right arrow




Tab




Backspace



Shift



ESC



Page up



Page down



F1



F2



F3



F4



F5



F6




F7



F8



F9



F10



F11




F12


USB Virtual COM Driver Installing

If you use virtual COM port emulation, please follow the steps below to start using the scanner.


1. Execute the driver (ZEBEX VCOM Driver Installation.exe).
2. Connect the scanner USB cable to the host computer.
3. Set the interface to USB Virtual COM Port.



Set



USB Virtual COM Port
*Driver required



End

4. On the computer, check Device Manager to see if the computer successfully detects the scanner as “Barcode Scanner USB-COM device.” (The COM port number would vary depending on different hardware environment).

