

To set the barcodes length with Programming Guide

a1.  Page 40
Start of Configuration

Code 39 Length Setting – MIN

a2.  Page 41
MIN

a3.  Page 55
1


a4.  Page 41
SET

a5.  Page 41
End of Configuration

b1.  Page 40
Start of Configuration

Code 128 Length Setting – MIN

b2.  Page 41
MIN

b3.  Page 55
1

b4.  Page 41
SET

b5.  Page 41
End of Configuration