


How to scan Code 128 with long characters?

If you need to scan a Code 128, for example, with maximum length of 36 characters, please follow the setting steps as below:

1. Start of configuration.



2. Code 128 length setting MAX.



3. 3



4. 6



5. Set



6. End of configuration.

