

Quick Guide

Please follow the steps to update the firmware.

1. Run [AutoHostV1_0.exe](#).
2. Choose the COM port what you connect.
3. Click "Search" to open the firmware file.
4. Press "Run" and the firmware would be updated in a while. After that, the unit will restart.

After the firmware is updated please switch back to the original cable and setup the scanner using the User's manual.

1. Scan "Start Of Configuration."
2. Scan "Return to USB default" or "Return to RS232 default" or "IBM PC/AT/PS/2 Keyboard emulation."
3. Scan "End Of Configuration."

Execute "Show version" to make sure the new version was updated.