

User's Manual

Compact Omnidirectional Laser Scanner



Revision History

Changes to the original manual are listed below:

Version	Date	Description of Version
1.0	2020/05/06	Initial release

Important Notice

No warranty of any kind is made in regard to this material, including, but not limited to, implied warranties of merchantability or fitness for any particular purpose. We are not liable for any errors contained herein nor for incidental or consequential damages in connection with furnishing, performance or use of this material. We shall be under no liability in respect of any defect arising from fair wear and tear, willful damage, negligence, abnormal working conditions, failure to follow the instructions and warnings, or misuse or alteration or repair of the products without written approval. No part of this document may be reproduced, transmitted, stored in a retrieval system, transcribed, or translated into any human or computer or other language in any form or by any means electronic, mechanical, magnetic, optical, chemical, biological, manual or otherwise, except for brief passages which may be quoted for purposes of scholastic or literary review, without express written consent and authorization. We reserve the right to make changes in product design without reservation and without notification. The material in this guide is for information only and is subject to change without notice. All trademarks mentioned herein, registered or otherwise, are the properties of their owners.

Specification or version may be subject to change without notice. The actual specification and version are based on the product delivered.

General Handling Precautions

- Do not dispose of the scanner in fire.
- Do not put the scanner directly in the sun or by any heat source.
- Do not use or store the scanner in a very humid place.
- Do not drop the scanner or allow it to collide violently with other objects.
- Do not take the scanner apart without authorization.

Printing Guidance

- This programming guide is in A5 size. Please double check your printer setting before printing it out.
- When printing barcodes for programming, the use of a high-resolution laser printer is strongly suggested for the best scan result.

Copyright © 2020. All rights reserved.

Radio Notice

Some equipment generates uses and can radiate radio frequency energy. If not installed and used in accordance with the instructions in this manual, it may cause interference to radio communications. The equipment has been tested and found to comply with the limits for a Class A computing device pursuant to EN55022 and 47 CFR, Part 2 and Part 15 of the FCC rules. These specifications are designed to provide reasonable protection against interference when operated in a commercial environment.

Radio and Television Interference

Operation of this equipment in a residential area can cause interference to radio or television reception. This can be determined by turning the equipment off and on.

The user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient the receiving antenna.

- Relocate the device with respect to the receiver.

- Move the device away from the receiver.

- Plug the device into a different outlet so that the device and the receiver are on different branch circuits.

If necessary, the user may consult the manufacturer, authorized dealer, or experienced radio/television technician for additional suggestions. The user may find the following booklet prepared by the Federal Communications Commission helpful: "How to Identify and Resolve Radio-TV Interference Problems." This booklet is available from the U.S. Government Printing Office, Washington, DC 20402 U.S.A., Stock No. 004000003454.

For CE-countries

This scanner is in conformity with CE standards. Please note that an approved, CE-marked power supply unit should be used in order to maintain CE conformance.

Laser Safety

The laser scanner complies with safety standard IEC 60825-1 for a Class I laser produce. It also complies with CDRH as applicable to a Class IIa laser product. Avoid long term staring into direct laser light.

Radiant Energy

The laser scanner uses one low-power visible laser diodes operating at 650nm in an opto-mechanical scanner resulting in less than 3.9 μ W radiated power as observed through a 7mm aperture and averaged over 10 seconds.

Do not attempt to remove the protective housing of the scanner, as un-scanned laser light with a peak output up to 0.8mW would be accessible inside.

Laser Light Viewing

The scan window is the only aperture through which laser light may be observed from this product. A failure of the scanner motor, while the laser diode continues to emit a laser beam, may cause emission levels to exceed those for safe operation. The scanner has safeguards to prevent this occurrence. If, however, a stationary laser beam is emitted, the failing scanner should be disconnected from its power source immediately.

Adjustments

Do not attempt any adjustments or alteration of this product. Do not remove the protective housing of the scanner. There are no user-serviceable parts inside.

Caution

Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous laser light exposure.

Optical

The use of optical instruments with this product will increase the eye hazard. Optical instruments include binoculars, magnifying glasses, and microscopes but do not include normal eye glasses worn by the user.

Table of Contents

Important Notice.....	iii
Radio Notice.....	iv
Laser Safety	v
Instruction.....	1
Unpacking.....	2
Outline	3
Scanner	3
Stand	4
Connecting.....	5
Power	5
Verifying Scanner Operation	5
Connecting to the Host	6
Setting up the Scanner	7
Scan Test.....	7
Set Up.....	7
Operation.....	8
Presentation Mode	8
Single Line Scan Mode	8
LED Indications.....	9
Beeps.....	10
Sleep Mode	10
Maintaining the Scanner.....	11
Cleaning the Scan Window	11
Replacing the Interface Cable	11
Dimensions.....	12
CHANGE THE SCANNER SETTING	13
Enter/Exit Programming Mode	13
DEFAULT PARAMETERS.....	14
PROGRAM PROCEDURE	19
System Setting.....	20
Reset (Return to Factory Default).....	21
Display Firmware Version.....	21
Abort (Exit Programming Mode).....	22
Return to RS-232 Default	22
Return as Customer Default	23
Return to USB Default	23
Save as Customer Default.....	24
How to Save as Customer Default	24
Sleep Timeouts Selection.....	25
Same Code Delay Time	33

Beeper Sound Selection	40
Barcode Identifier Code Setting	51
Barcode Identifier Code Selection	52
Set Message Format with Code Identifier	53
Enable Identifier Code Table as AIM Standard	53
Barcode Identifier Code Setting	54
Message delay.....	62
Character Delay.....	65
Interface Communication Setting	69
RS-232C Interface Configuration	70
Baud Rate Setting.....	70
Data Bit Setting	74
Stop Bit Setting.....	75
Parity Bit Setting.....	76
Handshaking Protocol	79
ACK/NAK Response Time Setting.....	82
Message terminator for RS-232C	88
Keyboard Wedge Interface Configuration.....	92
Message Terminator for Keyboard Wedge	92
Keyboard Language Selection	94
Capital Lock	100
Function Key Emulation	101
USB Interface Configuration.....	102
Keyboard Type.....	102
Message terminator for USB.....	103
Data Editing.....	105
HEADER AND TRAILER.....	106
Truncate Header/Trailer Character.....	108
Truncate Settings.....	110
Add Code Length	117
Symbology Configuration	118
Reading Code Selection.....	119
UPC/EAN Parameters Setting.....	130
Format.....	131
Force UPC-E to UPC-A format.....	135
Force UPC-A to EAN-13 format	136
Force EAN-8 to EAN-13 format.....	137
Transmit UPC-A check digit	139
Transmit UPC-E leading character	140
Transmit UPC-E check digit.....	141
Transmit EAN-8 check digit	142
Transmit EAN-13 check digit	143

Transmit UPC-A leading character.....	144
Addendum.....	145
Add on format	147
Data Redundant Check.....	157
Code 39 Parameters Setting.....	165
Code 39 reading length setting	169
Data Redundant Check.....	172
CODABAR Parameters Setting.....	174
Format.....	174
CODABAR Reading Length Setting.....	176
Check digit.....	178
Data Redundant Check.....	180
Code 128 Parameters Setting.....	182
Check Digit	182
Code 128 reading length setting	184
EAN-128 FNC1 Character	186
Data Redundant Check.....	187
ITF 2 of 5 Parameters Setting	189
Check Digit	189
ITF 2 of 5 reading length setting.....	191
Data Redundant Check.....	194
Chinese Post Code Parameters Setting	196
Chinese Post Code Reading Length Setting	196
Data Redundant Check.....	199
MSI/PLESSY Code Parameters Setting.....	201
Double Check Digit.....	201
Single Check Digit.....	203
MSI/PLESSY code reading length setting.....	204
Data Redundant Check.....	206
Code 93 Parameters Setting.....	208
Check Digit	208
Code 93 code reading length setting.....	210
Data Redundant Check.....	212
GS1 Databar Parameters Setting.....	214
Full ASCII Code Table	226
APPENDIX A.....	291
CODE 39 FULL ASCII CODE TABLE	291
APPENDIX B.....	293
FUNCTION KEY EMULATION.....	293

Instruction

The scanner is a compact hands-free omnidirectional laser scanner, and becomes a single-line laser scanner by pressing down a button. It is designed to suit both requirements for omnidirectional and single-line scanning. With the reserved mounting holes at the back of the scanner body, the scanner transforms to a scanning module to allow integration into your desirable hardware application.

The scanner is cubic designed as compact as it can be, and with its standard holder, it certainly saves the maximum counter top space. Featured with Z-scan hardware decode technology, it guarantees the real-time decode and provide the best scanning performance you could expect. The scanner surely has the performance inverse to its size.

The scanner includes key features as,

- Button switch in between omnidirectional and single-line scanning capability, ideal for increasing your operating efficiency.
- Powerful 20-line scan pattern yields
 - 1400 scans per second for omnidirectional scanning;
 - 74 scans per second for single-line scanning.
- Implement with the proprietary real-time hardware decoding technology that ensures instant recognition and decoding barcodes.
- Instant working is ready, or can be embedded into other hardware applications via mounting holes at back.
- Optional 3D turning cradle with two joins that maximize the range of adjustment.

Unpacking

The handheld omnidirectional scanner package contains:

1 ea. Compact omnidirectional scanner



1 ea. Scanner stand



1 ea. Screw
(to fix the stand when necessary)



1 ea. Adjustable stand (optional)



1 ea. Communication cable



1 ea. Power adapter
(only for specific RS-232 cables as optional accessory)



- *If any contents are damaged or missing, please contact your dealer immediately.*

Outline

Scanner



Description	Function
Exit Window	Reads barcodes
Object Detector	Trigger and wake up scanner when presenting barcode in its range
Beeper Hole	For beep tone indication
Function Button	<p><u>Wake up scanner</u></p> <p>When the scanner enters into the sleep mode, pressing this switch can wake the scanner up. The sleep mode feature can be programmed by using the menu labels from the Programming Guide.</p> <div data-bbox="367 963 471 1082"> </div> <ul style="list-style-type: none"> ➤ The default time-out setting for the sleep mode is to switch off laser after 10 minutes, and switch off motor after 30 minutes. ➤ When the scanner is in the sleep mode, the LED is intermittently flashing blue. <p><u>Single -line pattern</u></p> <p>Pick up the scanner, press and release the trigger will activate single line scan mode</p>
Back Mount Holes	To fix the scanner with your host instrument.
Interface Cable Connection	For interface communication cable connection.

Stand

Both stands are designed with a fixing hole. Use appropriate screws enclosed in the package to fix the stands on surface if necessary.

Fixed Stand

Screw Size:

Sharp screw,
M4-16.0mm,
Cross shape




Adjustable Stand

Screw Size:

Sharp screw,
M5-16.0mm,
Cross shape



Adjustable height illustrate as below,



Connecting

Power

The scanner requires a minimum of 2.5W at 5 VDC power. The interface cable that comes with the scanner supports both direct power (where the scanner takes power from the host machine) and external power (that's what the supplied power adapter is for). A sufficiently robust POS system can support a scanner successfully without external power; a POS system with a barely adequate power supply may produce erratic performance (either of the POS system itself, or of the scanner, or both) when a scanner is attached. Unless you are sure your POS system can handle such loading, it is recommended that you use the supplied power adapter. When an external adapter is connected, the scanner does not take power from the host.

The scanner turns on when power is supplied, and turns off when power is removed. There is no on/off switch on the scanner itself.

Use only an AC/DC power adapter approved for the scanner. Use of other power supplies may cause damage to the scanner, and void the factory warranty.

Verifying Scanner Operation

Please follow the procedure below to verify scanning operation.

1. Insert the 8 pin modular plug of the Interface cable into the scanner until a firm click is heard.
2. Plug the power adapter into the jack on the interface cable if necessary.
3. Plug the AC end of the power adapter into an AC outlet, or plug the other end of cable into host if power adapter is not needed. When power is supplied, the scanner powers up, the buzzer sounds four beeps and the LED indicator glows.
4. Present a known-good test barcode to the scanner. The scanner should issue a short beep and the LED should flash red momentarily. [If the scanner is connected to a USB for this test, it should read one barcode, beep and then remain a red LED indicating light. This is normal when the USB is not connected to a live host terminal.]

- *If the scanner does not produce any beeps, or produces the wrong beeps, or the LED does not light up, remove the power connection and refer to the Troubleshooting section.*

Connecting to the Host

The interface cable comes with different host-end connectors, depending on the host. Follow the steps below to connect the interface cable to the host.

1. Make sure that the power of the host system is off.
2. Connect the host end of the interface cable to the appropriate connector on the host system.
3. For those cases where external power is used, plug the external AC power adapter into the jack on the interface cable.
4. Turn on the host system.

Setting up the Scanner

In certain cases no setup is required. The scanner is either pre-programmed to suit the situation, or it automatically detects and is ready to go. In other cases the scanner must be informed about what kind of system it is connected to. This can be done in a few moments using the programming barcodes in the Programming Guide.

The programming section may be used to set a number of parameters on the scanner: communication interface type (RS-232, Keyboard, USB), beep tone, sleep mode timings, same-code delay time, enable/disable decoding of numerous code types, and more advanced things like set headers and trailers.

Individual parameters may be set at any time without affecting the other parameters.

Scan Test

1. With the scanner running (LED blue) and the host system on, try to scan several known-good barcodes.
2. Check the results on the POS screen. If the scanner is reading okay, it is likely that no further setup is necessary.
3. If the POS screen does not show the expected scans, go to the Set Up section below.

Set Up


1. When the scanner is powered on (LED blue), find the <Enter/Exit programming mode> barcode and present this barcode to the scanner. When the scanner gives two beeps (one low and one high) and the LED turns red, it means the scanner is in programming mode.
2. Decide which parameters are required and find their barcodes in the Programming Guide.
3. Cover unwanted codes with your hand and present the desired codes, one by one, to the scanner, the scanner beeps once as it accepts each code.
4. When done, again present the <Enter/Exit programming mode> barcode. The scanner beeps twice, once long and once short, and the LED returns to blue. The scanner has been programmed.
5. Test again with known-good barcodes. If results are good, you are done setting up. Otherwise, return to step 1 and try again.

Operation

The scanner can read barcodes in either omnidirectional or single-line mode to accommodate different requirements. This scanner is truly omnidirectional while single-line mode is usually used for better aiming on the specific barcode on the same sheet of more than one barcode printed closely.

Presentation Mode

As the scanner is on the stand, the scanner would always stay active in the Presentation Mode. In other words, the scanner always has multi-lines, and would not switch to single-line scan when the button is pressed down.



Single Line Scan Mode

In this mode the scanner can emit a single line pattern for users to handheld scanning of hard-to-read or multiple barcodes on one object. Sales clerks can switch it to single line scan option simply by pressing one button.



1. Pick up the scanner.
2. Press and then release the top button and a line pattern would appear. It allows you to aim at the barcode.

3. Ensure the scan line crosses every bar and space of the symbol.



4. Press the button to decode and transmit the barcode, the good read beeps once.



- *If the button is released, it automatically switches back to omnidirectional scan in 5 seconds. Press down again to switch to single-line scan when necessary.*

LED Indications

A dual color red-blue LED indicates operating status as follows:

LED Status	Indication
Off	No power supplied to the scanner.
Steady blue light	The scanner is on and ready to scan.
One red flash	A barcode has been successfully decoded.
Steady red light	A barcode has been successfully decoded, but the object is not removed from the scan window.
Steady red light	The scanner is in programming mode.
Flashing blue light	The scanner is in sleep mode.
Steady purple light	This indicates the scanner has a motor or laser failure. For motor failure, a periodic beep is sounded. In this case, return the unit for repair.
Alternate flashing red and blue light	The scanner detects failing power. Please check the power supply.

Beeps

A beeper gives audible feedback on scanner operation.

Beeps	Indication
One beep	A barcode has been successfully decoded.
Four beeps in series	This indicates the scanner passed the power on self-test and is operating properly.
Two beeps: low-high	The scanner has entered programming mode.
Two beeps: same tone	Scanner has returned from programming to normal mode.
Continuous tone	This is a failure indication. Return the unit for repair.

Sleep Mode

After the scanner has been inactive for a period of time, the laser would automatically turn off; then the motor would also turn off and the scanner would enter the "Sleep Mode." The blue status LED blinks once as indication. To wake up the scanner, simply present an object close to the exit window, or press the trigger button.

- The scanner includes a motion sensor that detects activity in front of the scan window. The detecting distance is up to about 15cm (6 inches) from the scan window.

Maintaining the Scanner

The scanner is designed for long-term trouble-free operation and rarely requires any maintenance. Only an occasional cleaning of the scanner window is necessary in order to remove dirt and fingerprints.

Cleaning the Scan Window

Wipe the scan window with a soft lint-free cloth and a non-abrasive cleaner to avoid scratching and damaging the scan window. The scan window may be cleaned while the scanner is running.


Replacing the Interface Cable

The standard interface cable is attached to the scanner with a 10-pin modular connector. When the connector is properly seated, it is secured in the scanner by a flexible retention tab. The cable is designed to be field replaceable.


Replacement cables can be obtained from your authorized distributor.

Take the following steps to replace the cable:

1. Make sure that the power of your computer is switched off, and if a power adapter is used, disconnect it from the scanner cable.
2. Disconnect the old scanner cable from the computer system.
3. Press down at where indicated below, and gently pull out the cable.
4. Insert the new interface cable into the bottom of the scanner until it clicks.
5. Plug the new cable into the host.
6. If a power adapter is used, plug the power adapter into the jack on the interface cable.



Dimensions




CHANGE THE SCANNER SETTING

In order to change the scanner setting, please follow the steps below:

1. Scan the **Enter/Exit Programming Mode** barcode. There will be 2 beeps (low-high) indicating ready to make settings.
2. Scan barcodes for the desired feature (1 beep)
3. Scan the **Enter/Exit Programming Mode** barcode again to save the configuration. There will be 2 beeps (long-short) indicating a successful setting.

After reading a valid barcode in programming mode, the scanner will give a high beep.

Enter/Exit Programming Mode




(This barcode can also be found at back cover page.)

Framed values are default values.

DEFAULT PARAMETERS

This table gives the default settings of all the programmable parameters. The default settings will be restored whenever the **Reset** programming label is scanned. (This label can also be found on p.8.)

Reset (Return to factory default)



Default Values of Operating Parameters

<i>Function</i>	<i>Default</i>
Sleep mode	
Motor sleep mode	After 30 minutes
Laser sleep mode	After 10 minutes
Scanner timing	
Same code delay	200msec
Beeper Tone	
Frequency	medium
Duration	50msec
Code Identifiers	
Code ID	off
Code 39	M
ITF 2 of 5	I
Chinese post code	H
UPC-A	A
UPC-E	E
EAN-13	F
EAN-8	FF
Codabar	N
Code 128	K
Code 93	L
MSI/Plessy	P
GS1 DataBar Omnidirectional (Formally RSS-14 Standard)	RS
GS1 DataBar Limited (Formally RSS Limited)	RL
GS1 DataBar Expanded (Formally RSS Expanded)	RX

Default Values of Serial Communication Parameters

Function	Default Values
Handshaking protocol	None
ACK/NAK response time setting	300 msec
Baud rate	9600
Data bit	8
Stop bit	1
Parity	None
Message terminator selection	CR/LF

Default Values of USB Emulation Parameters

Function	Default Values
Keyboard Type	US Keyboard
Message Terminator	Enter

Default Values of Decoding Parameters

Function	Code	Default Value
Reading codes selection	Code 39	Enable
	ITF 2 of 5	Disable
	Chinese Post Code	Disable
	UPC/EAN/JAN	Enable
	Codabar	Disable
	MSI/PLESSY	Disable
	Code 128	Disable
	Code 93	Disable
	EAN-128	Disable
	Italian Pharmacy	Disable
	ISSN/ ISBN	Disable
	GS1 DataBar (RSS)	Disable
Code 39	Codes	Standard
	Start/stop characters	Not transmitting
	Check digit	Disabled
	Concatenation	Off
	Length	3~32
Interleaved 2 of 5	Length	6-32
	Check digit	Disable
Chinese Post Code	Length	10~32
	Check digit	Disable
UPC/EAN/JAN	Format	All
	Addendum	Disable
	UPC-E=UPC-A	Disabled
	UPC-A leading digit	Transmit
	UPC-A check digit	Transmit
	UPC-E leading digit	Transmit
	UPC-E check digit	Transmit
Codabar	Type	Standard
	Start/stop characters	A, B, C, D
	Length	6~32 digits
Code 128	FNC 2 append	Disable
	Check digit	Disable
Code 93	Length	3~32
	Check digit	Not transmit
MSI	Length	6~32
	Check digit	Transmit
Italian Pharmacy	Transmit "A" Character	Not transmitting


Default Values of Decoding Parameters (continued)

Function	Code	Default Value
GS1 DataBar (formally RSS)	GS1 DataBar Omnidirectional	Disable
	GS1 DataBar Limited	Disable
	GS1 DataBar Expanded	Disable
	Transmit GS1 DataBar Omnidirectional check digit	Enable
	Transmit GS1 DataBar Omnidirectional application ID (01)	Enable
	Transmit GS1 DataBar Limited check digit	Enable
	GS1 DataBar Omnidirectional/EAN-128 emulation	Disable
	Transmit GS1 DataBar Limited application ID (01)	Enable
	Transmit GS1 DataBar Expanded check digit	Enable
	Transmit AI(01) of Expanded	Enable
	GS1 DataBar Expanded /EAN-128 emulation	Disable

NOTE:

Contact your distributor to make sure if your model and firmware version support GS1 DataBar.

PROGRAM PROCEDURE




System Setting

The series scanner is a multi-interface communication scanner. If you had ordered only one type of interface, the device is configured in the interface requested, i.e. RS-232C, keyboard wedge, or USB. If not requested, the default interface is set in keyboard wedge interface (PC/AT). Use this section to change interfaces.

Reset (Return to Factory Default)

Reading of “Reset” barcode label turns all parameters back to default values, and the scanner remains in the last interface set when it is reset.

Reset (Return to Factory Default)




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Display Firmware Version

Reading of the “Display Firmware Version” will show the current firmware version on host.


Display Firmware Version



Abort (Exit Programming Mode)

Reading of the “Abort” barcode label discards all the parameters read prior to scan the “Enter/Exit of Programming Mode”.

Abort (Exit Programming Mode)




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Return to RS-232 Default

The RS-232C interface scanner is often used when connecting to the serial port of a PC or terminal. Read the barcode to set the scanner into RS-232 interface.


Return to RS-232 Default



Return as Customer Default

Reading of the label sets the device back to customer saved parameter settings.

Return as Customer Default




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Return to USB Default

Reading of “Return to USB default” sets the device into USB interface support.


Return to USB Default




Save as Customer Default

Reading of this label to save the desired parameters set into customer's own default setting.

Save as Customer Default



How to Save as Customer Default




Sleep Timeouts Selection

In this section, user can set both laser and/or motor to enter into sleep mode. The timeout programming labels will allow users to set the different time frame before entering into laser and/or motor sleep mode. The feature reduces power consumption and prolongs scanner life time.

NOTE:


1. **Laser always enters sleep mode before motor.**
2. **If the motor timeout is set shorter than the motor timeout, then laser would enter sleep mode as motor enters sleep mode.**

Motor sleep mode off




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Motor sleep time 5 min.




Motor sleep time 10 min.




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Motor sleep time 20 min.





Motor sleep time 30 min.




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Motor sleep time 60 min.




Laser sleep mode off

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


Laser sleep time 5 min.

Laser sleep time 10 min.




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Laser sleep time 15 min.




Laser sleep time 20 min.




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Laser sleep time 25 min.




Laser sleep time 30 min.



Same Code Delay Time


This parameter sets the minimum time allowed between decodes of the same label.

Same code delay time 50 msec.




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Same code delay time 100 msec.




Same code delay time 200 msec.




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Same code delay time 300 msec.




Same code delay time 400 msec.




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Same code delay time 500 msec.




Same code delay time 600 msec.




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Same code delay time 700 msec.




Same code delay time 800 msec.




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Same code delay time 900 msec.




Same code delay time 1000 msec.




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Same code delay time infinite




Beeper Sound Selection


This section includes all setting labels for beeper sound settings, including tone frequency, volume, duration time, power on beep enable/disable, and enable/disable sound when the scanner enters sleep mode.

LED/Beep after transmission

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


LED/Beep before transmission


Power-up tone enable




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Power-up tone disable




Sleep sound

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


Sleep silent


Medium beeper tone




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Low beeper tone




High beeper tone

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


Speaker disable


Beeper sound duration (100msec)




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Beeper sound duration (50msec)




Beeper sound duration (20msec)

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


Beeper sound duration (5msec)

Beeper sound duration 200msec




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Beeper sound duration 500msec




Loud beeper volume




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Medium beeper volume



Low beeper volume



Barcode Identifier Code Setting

The scanner can transmit maximum 2 digits barcode identifier code for different types of barcodes. Use Enable or Disable identifier setting barcode to determine the transmission of barcode ID.

The procedure is as follows:

- 1.) Scan **Enter/Exit Programming Mode** label
- 2.) Scan **Barcode Identifier Setting Code** label
- 3.) Scan the new code mark from ASCII table (maximum 2 digits). For example, if **AB** is the code mark, then scan **A** and **B**.
- 4.) Scan **Save Setting to Confirm** label
- 5.) Scan **Enter/Exit Programming Mode** label

Barcode Identifier Code Selection




Scan “Enable identifier code” label to transmit the label ID as shown in the table below.

Code 39	M
ITF 2 of 5	I
Chinese post code	H
UPC-A	A
UPC-E	E
EAN-13	F
EAN-8	FF
Codabar	N
Code 128	K
Code 93	L
MSI/Plessy	P
GS1 DataBar Omnidirectional (RSS-14 Standard)	RS
GS1 DataBar Limited (RSS Limited)	RL
GS1 DataBar Expanded (RSS Expanded)	RX




Set Message Format with Code Identifier




Code	Code identifier
UPC-A	A
UPC-E	E
EAN-8	FF
EAN-13	F
CODE 39	*
CODBAR	%
ITF 2 OF 5	i
CODE 93	&
CODE 128	#
MSI/PLESSY	@
EAN-128	P

Enable Identifier Code Table as AIM Standard




Barcode Identifier Code Setting

Code 39 identifier code setting




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

ITF 2 of 5 identifier code setting





Chinese Post code identifier code setting




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


UPC-E identifier code setting




UPC-A identifier code setting


To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

EAN-13 identifier code setting


EAN-8 identifier code setting


To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Codabar identifier code setting


Code 128 identifier code setting


To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Code 93 identifier code setting


MSI identifier code setting


To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Save setting to confirm

GS1 DataBar Omnidirectional identifier code setting

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


GS1 DataBar Limited identifier code setting

GS1 DataBar Expanded identifier code setting

Message delay


This section contains different delay time frames between two consecutive messages. This delay will be added before each data transmission.

Inter message delay 0 ms




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Inter message delay 100 ms




Inter message delay 500 ms




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Inter message delay 1000 ms




Character Delay


This option governs delay time between two consecutive characters; the delay time can be altered by scanning the following labels.

Character delay 5 ms

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


Inter character delay 0 ms

Inter character delay 10 ms




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Inter character delay 20 ms



Inter character delay 50 ms



Interface Communication Setting


This section contains labels to configure the scanner to user's host terminal. The following interfaces are supported:

- *RS-232C interface
- *Keyboard wedge
- *USB interface

RS-232C Interface Configuration


Baud Rate Setting


Baud Rate 38400




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Baud Rate 19200




Baud Rate 9600

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


Baud Rate 4800


Baud Rate 2400




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Baud Rate 1200




Baud Rate 57600

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Baud Rate 115200


Date Bit Setting

7 data bit



To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

8 data bit



Stop Bit Setting




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.




Parity Bit Setting


Even Parity




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Odd Parity



Mark Parity

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Space Parity



Handshaking Protocol

The RS-232C type scanner supports four handshaking protocols. With these options of communication protocol, users can tailor the scanner to meet the requirement of most systems. These handshaking protocols are:

***None**

The scanner will transmit any read data unconditionally. The scanner will not check the receiving device or the transmitted message.

***RTS/CTS**


Under this handshaking protocol, the scanner use the RTS pin to instruct the connected device to transmit data and test the CTS pin for readiness of the connected device to receive data.

***ACK/NAK**


The scanner waits for an ACK or NAK signal from the host computer after each data transmission. Normally, the scanner will temporarily stored the scanned data in the memory buffer before receiving the ACK or NAK signal. If the ACK signal is received, it will clear the transmitted data and continue to send the next data. In case the NAK signal is received, it will repeat to transmit the same data until receiving the ACK signal.


***Xon/Xoff**

During the data communication, if a scanner receives an Xoff (ASCII 013H), it will stop the transmission at once. The scanner waits for a Xon (ASCII 01H) to start the transmission again.


None handshaking

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

ACK/NAK


Xon/Xoff

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

RTS/CTS


ACK/NAK Response Time Setting


ACK/NAK response time 300ms




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


ACK/NAK response time 500ms




ACK/NAK response time 1s


To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

ACK/NAK response time 2s


ACK/NAK response time 3s

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

ACK/NAK response time 5s


ACK/NAK response time Infinity

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


Disable ACK/NAK timeout beeper

Enable ACK/NAK timeout beeper

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Enable beeper on<BEL> character


Ignore beep on <BEL>character



Message terminator for RS-232C


The series RS-232C type scanner can be programmed to append a terminator to every message sent via the serial port. Different terminator will be appended at the end of message sent from the serial port.


RS-232 message terminator — none




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


RS-232 message terminator — CR/LF




RS-232 message terminator — CR

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


RS-232 message terminator — LF

RS-232 message terminator — H tab

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

RS-232 message terminator — STX/ETX


RS-232 message terminator—EOT



Keyboard Wedge Interface Configuration


Message Terminator for Keyboard Wedge


Keyboard terminator---none



To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


Keyboard terminator---Enter



Keyboard terminator---H-TAB


Keyboard Language Selection


Enable International keyboard type
(Alt method)




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


Keyboard language support---USA




Keyboard language support---Germany


To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Keyboard language support---UK


Keyboard language support---French

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


Keyboard language support---Spanish

Keyboard language support--- Italian

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


Keyboard language support--- Swiss

Keyboard language support---Swedish




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Keyboard language support---Japanese




Keyboard language support---Belgium



To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


Keyboard language support---Turkish



Capital Lock


Select the suitable code to match your keyboard caps lock status.

Capital lock on



To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


Capital lock off



Function Key Emulation


In this section, users can emulate Function keys, Arrow keys, and many other extended keys. An IBM compatible keyboard does not translate to ASCII characters; it can be concatenated with input data as header and/or trailer. (See Appendix B)

Function key emulation enable



To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Function key emulation disable



USB Interface Configuration

The USB mode is effectively a keyboard emulator that works with hosts, such as USB-compatible operating system and USB ports. USB compatible operating systems are Windows 98, Windows NT 5.0 and later. No additional software is needed since the USB driver supports its built-in operating system

Keyboard Type




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.




Message terminator for USB



To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.



H tab




Data Editing


HEADER AND TRAILER

The **Header and Trailer** section allows you to append a header and/or a trailer to every message transmitted via the serial ports, USB or the keyboard port. There is no restriction in selecting header or trailer characters as far as the sum of the lengths of header and trailer is not greater than 10 digits.


1. Select either header or trailer you are going to program by scanning the corresponding label
2. Scan the character(s) you want from the ASCII table to set as header or trailer. (Be sure to enable full ASCII code 39 option before you start.)
3. Read the **save setting to confirm** label to confirm your choice into memory.

Header (Preamble)



Trailer (Postamble)


To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Save setting to confirm


Truncate Header/Trailer Character

This setting allows you to truncate a number of header or trailer for symbology. As a result, the specific characters you select are deleted (or keep if the reverse setting is set) from the symbology you want.

- 1.) Scan the **Enter/Exit programming mode** label.
- 2.) Select the **Truncate header or truncate trailer** label.
- 3.) Scan two barcode value from the full ASCII code table(0~9). For example, scan **0** and **2** if you want to clear the number **2** from header.
- 4,) Scan **save setting to confirm** label
- 5,) Scan **Enter/Exit programming mode** label to end of configuration.

Truncate header character

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Truncate trailer character

Truncate Settings

- Truncate character default setting allows you enable the truncate function. EX: setting of truncate 4 header characters in EAN-13 001234567895 will appear as 34,567,895.
- Truncate character reverse setting allows you to enable the truncate reverse function. Reverse truncate allows you to save the specific character you select. EX: Reverse truncate 4 header characters EAN-13 001234567895, the first 4 characters 0012 are saved.
- Disable all barcode for truncate setting allows you to disable all truncates settings; once disabled, you can choose to enable all by scanning "Enable all barcode for truncate setting" or enable a single barcode truncate setting such as EAN13 or Code 39.

Truncate character default

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Truncate character reverse

Enable all barcode for truncate setting



To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Disable all barcode for truncate setting



Enable EAN13 for truncate setting



To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Enable EAN8 for truncate setting



Enable UPC-A for truncate setting



To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Enable UPC-E for truncate setting



Enable Code39 for truncate setting

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Enable I25 for truncate setting

Enable Code128 for truncate setting


To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Enable Codabar for truncate setting

Add Code Length


This option allows you to add the reading barcode numeric characters as header

Add code length as header enable (all barcode)



To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Add code length as header disable (all barcode)




Symbology Configuration

In this section, device can be programmed to recognize one or more barcode symbologies automatically. If the scanner is configured to support multiple barcode symbologies, the scanner will discriminate different symbologies automatically. However, to improve scanning performance, you should enable only the symbologies that will be in active use.


Reading Code Selection


Code 39 enable




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


Code 39 disable



Codabar enable


To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Codabar disable


UPC/EAN/JAN enable


To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

UPC/EAN/JAN disable**(only can't transmitted but can decode)**


ITF 2 of 5 enable


To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

ITF 2 of 5 disable


Chinese postcode enable


To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Chinese postcode disable


Code 128 enable

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


Code 128 disable

Code 93 enable

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


Code 93 disable


EAN-128 enable




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


EAN-128 disable




EAN convert to ISSN/ISBN


To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

EAN convert to ISSN/ISBN disable


Code 32 enable

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Code 32 disable

MSI enable

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

MSI disable

UPC/EAN Parameters Setting

In this section, device can be programmed to recognize some or all derivatives of UPC/EAN.


These derivatives are UPC-A, UPC-E, EAN-8, and EAN-13. Either 2 or 5 addendum digits is supported, addendum digits are those additional digits after normal stop character.

The programming menu for UPC/EAN/JAN also provides several options to govern the transmission of scanned data.

- *UPC/EAN expansion
- *Check digit transmission
- *Data redundant check
- *Addendum seek timeout
- *Addendum left/right margin adjust


Format


UPC/EAN/JAN all enable




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


EAN-8 or EAN-13 enable




UPC-A and EAN-13 Enable

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


UPC-A and UPC-E Enable

UPC-A enable

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


UPC-E enable

EAN-13 enable




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

EAN-8 enable




Force UPC-E to UPC-A format

Force UPC-E to UPC-A format enable




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Force UPC-E to UPC-A format disable




Force UPC-A to EAN-13 format

Force UPC-A to EAN-13 format enable




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Force UPC-A to EAN-13 format disable




Force EAN-8 to EAN-13 format

Force EAN-8 to EAN-13 format disable




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Force EAN-8 to EAN-13 format enable




EAN-13 first "0" can transmitted




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

EAN-13 first "0" can't transmitted




Transmit UPC-A check digit

Transmit UPC-A check digit enable




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Transmit UPC-A check digit disable




Transmit UPC-E leading character

Transmit UPC-E leading character enable




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Transmit UPC-E leading character disable




Transmit UPC-E check digit

Transmit UPC-E check digit enable




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Transmit UPC-E check digit disable




Transmit EAN-8 check digit

Transmit EAN-8 check digit enable




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Transmit EAN-8 check digit disable




Transmit EAN-13 check digit

Transmit EAN-13 check digit enable




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Transmit EAN-13 check digit disable




Transmit UPC-A leading character

Transmit UPC-A leading character enable




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Transmit UPC-A leading character disable




Addendum

UPC/EAN add on off




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Add on 5 only



Add on 2 only




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Add on 2 or 5




Add on format

Add on format with separator




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Add on format without separator




EAN/UPC +Add on (none mandatory)




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

EAN/UPC + Add on(mandatory)




**EAN/UPC + add on mandatory for 378/379 French Supplement
requirement not sent for other**



To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


**EAN/UPC +add on mandatory for 978/977
book land Supplement requirements
Not sent for other**



EAN/UPC + addon mandatory for 434/439

German Supplement requirement

Not sent for other




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


EAN/UPC + add on mandatory for 419/414

Euro amounts Supplement requirement

not sent for other




EAN/UPC + add on mandatory for 378/379
French Supplement requirement
optionally for other




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

EAN/UPC + add on mandatory for 978/977
Book land Supplement requirement
optionally for other




EAN/UPC + add on mandatory for 434/439
 German Supplement requirement
 optionally for other




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

EAN/UPC + add on mandatory for 419/414
 Euro amounts Supplement requirement
 optionally for other




EAN/UPC + add on mandatory for 491
Japanese (bookland) Supplement
requirement optionally for other




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

EAN/UPC + add on mandatory for 491
Japanese (bookland) Supplement
requirement Not sent for other





Double code not allowed




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


Double code mandatory for 978/192



Double code format without separator

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Double code format with separator


Double code format with free (one character)

Data Redundant Check

In this section, user can set decoder data redundant check, before it is accepted as a good read. A higher data redundant check read setting offers more assurance that a barcode has been read correctly, while a lower setting allows faster scanning performance.


UPC-A Data Redundant Check

UPC-A data redundant check = 0




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

UPC-A data redundant check = 1





UPC-A data redundant check = 2




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

UPC-A data redundant check = 3




UPC-E Data Redundant Check**UPC-E data redundant check = 0**

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


UPC-E data redundant check = 1


UPC-E data redundant check = 2




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

UPC-E data redundant check = 3




EAN-13 Data Redundant Check**EAN-13 data redundant check = 0**

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


EAN- 13 data redundant check = 1


EAN-13 data redundant check = 2




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


EAN-13 data redundant check = 3




EAN-8 Data Redundant Check**EAN-8 data redundant check = 0**

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

EAN-8 data redundant check = 1

EAN-8 data redundant check =2

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


EAN-8 data redundant check = 3

Code 39 Parameters Setting

The scanner can be programmed to support the standard code 39 or Full ASCII code 39. In addition, it is user's option to transmit or not to transmit the start and stop characters. You can also enable or disable the check digit feature. If the check digit feature is enabled, you have the further option to decide whether the check digit is transmitted or not.


Character Set

Standard code 39




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

FULL ASCII code 39




Start/Stop Character Transmission

Code 39 start/stop character transmission




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Code 39 start/stop character without transmission




Check Digit

Code 39 check digit calculate and transmit



To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Code 39 check digit calculate but without transmit







Code 39 reading length setting

The default code 39 length is 3 ~32 character. It can be set at minimum 1 digit and maximum 62 digits.


CODE LENGTH SETTING PROCESS



Code 39 maximum length setting




Code 39 minimum length setting




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Save setting to confirm




Code 32 "A" Character Transmit

Code 32 (Italian pharmacy) transmit "A" character



To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


Code 32(Italian pharmacy) without transmitting "A" character



Data Redundant Check


In this section, users can use labels to set decoder data redundant check before it is accepted as a good read. A higher data redundant check read setting offers more assurance that a barcode has been read correctly while a lower setting allows faster scanning performance.

Code 39 data redundant check = 0




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Code 39 data redundant check = 1




Code 39 data redundant check = 2



To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Code 39 data redundant check = 3




CODABAR Parameters Setting

In this section, there are varies settings for Codabar symbology, including:

- Check character verification or transmission
- CODABAR concatenation
- Data redundant check
- Start/Stop Characters
- Min./Max. length setting


Format

Codabar start/stop character transmission ----none




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Codabar start/stop character transmission ---- A,B,C,D




Codabar start/stop character transmission ---- DC1~DC4



To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


Codabar start/stop character transmission ---- a/t,b/n,c/*,d/e




CODABAR Reading Length Setting


The default CODABAR length is 6 ~32 character. It can be set at minimum 1 digit and maximum 62 digits

CODE LENGTH SETTING PROCESS




Codabar maximum length setting



Codabar minimum length setting

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


Save setting to confirm

Check digit




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Check digits calculate but not transmit




Check digit calculate and transmit



Data Redundant Check


In this section, users can set decoder data redundant check before it is accepted as a good read. A higher data redundant check read setting offers more assurance that a bar code has been read correctly while a lower setting allows faster scanning performance.

Codabar data redundant check = 0




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Codabar data redundant check = 1




Codabar data redundant check = 2



To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Codabar data redundant check = 3




Code 128 Parameters Setting

In this section, there are varies setting for Code 128 symbology, including:

- Check character verification or transmission
- FNC2 concatenation
- Data redundant check
- FNC1 transmission for EAN-128
- **Min./Max. length setting**


Check Digit

No check character




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Calculate but not transmit




Calculate and transmit




Code 128 reading length setting


The default code 128 length is 3 ~62 character. It can be set at minimum 1 digit and maximum 62 digits

CODE LENGTH SETTING PROCESS




Code 128 maximum length setting




Code 128 minimum length setting

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Save setting to confirm


EAN-128 FNC1 Character

EAN-128 FNC1 Character transmitted



To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


EAN-128 FNC1 not character transmitted



Data Redundant Check


In this section, users can set decoder data redundant check before it is accepted as a good read. A higher data redundant check read setting offers more assurance that a bar code has been read correctly while a lower setting allows faster scanning performance

Code 128 data redundant check = 0




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Code 128 data redundant check = 1




Code 128 data redundant check = 2



To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Code 128 data redundant check = 3




ITF 2 of 5 Parameters Setting

In this section, there are varies ITF 2 of 5 symbology including:

- Check character verification or transmission
- Data redundant check
- Two fixed length setting
- **Min./Max. length setting**


Check Digit

ITF 2 of 5 no check character




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

ITF 2 of 5 check digit calculate and transmit




ITF 2 of 5 check digit calculate but without transmit




ITF 2 of 5 reading length setting

The default ITF 2 of 5 length is 6 ~32 character. It can be set at minimum 2 digit and maximum 62 digits


CODE LENGTH SETTING PROCESS



ITF 2 of 5 code maximum length setting




ITF 2 of 5 code minimum length setting




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Save setting to confirm




ITF 2 of 5 one fixed length setting



To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


ITF 2 of 5 two fixed length setting



Data Redundant Check


In this section, users can set decoder data redundant check, before it is accepted as a good read. A higher data redundant check read setting offers more assurance that a bar code has been read correctly, while a lower setting allows faster scanning performance

ITF 25 data redundant check =0




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

ITF 25 data redundant check = 1




ITF 25 data redundant check = 2



To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

ITF 25 data redundant check = 3



Chinese Post Code Parameters Setting

In this section, there are varies Chinese post code symbologies including:


- Data redundant check
- **Min./Max. length setting**

Chinese Post Code Reading Length Setting


The default Chinese post code length is 10 ~32 character. It can be set at minimum 1 digit and maximum 62 digits.

In order to avoid missing characters when scanning is incomplete, we recommend using a short-range length or fixed length.

CODE LENGTH SETTING PROCESS




Chinese post code maximum length setting




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Chinese post code minimum length setting




Save setting to confirm



Data Redundant Check


The option allows you to set decoder data redundant check before it is accepted as a good read. A higher data redundant check read setting offers more assurance that a bar code has been read correctly while a lower setting allows faster scanning performance


Chinese post code data redundant check = 0




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Chinese post code data redundant check = 1



Chinese post code data redundant check = 2

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Chinese post code data redundant check = 3


MSI/PLESSY Code Parameters Setting

In this section, there are varies set up for Chinese post code symbology, including:

- Check character verification or transmission
- Data redundant check
- **Min./Max. length setting**


Double Check Digit

MSI/PLESSY double check digit calculate but not transmit




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

MSI/PLESSY double check digit without calculate and transmit




MSI/PLESSY double check digit calculate but only first digit transmit




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

MSI/PLESSY double check digit calculate and both transmit




Single Check Digit

MSI/PLESSY single check digit calculate but without transmission



To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


MSI/Plessy single check digit calculate and transmit




MSI/PLESSY code reading length setting


The default MSI/PLESSY code length is 6~32 character. It can be set at minimum 1 digit and maximum 62 digits

CODE LENGTH SETTING PROCESS




MSI/PLESSY maximum length setting



MSI/PLESSY minimum length setting


To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Save setting to confirm

Data Redundant Check


The option allows you to set decoder data redundant check before it is accepted as a good read. A higher data redundant check read setting offers more assurance that a barcode has been read correctly while a lower setting allows faster scanning performance

MSI data redundant check = 0




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

MSI data redundant check = 1




MSI data redundant check = 2



To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

MSI data redundant check = 3




Code 93 Parameters Setting

In this section, there are varies set up for Code 93 symbology, including:

- Check character verification or transmission
- Data redundant check
- **Min./Max. length setting**


Check Digit

Code 93 check digit calculate but without transmit




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Code 93 check digit not calculate and without transmit




Code 93 check digit calculate and transmit




Code 93 code reading length setting


The default Code 93 code length is 3 ~32 character. It can be set at minimum 1 digit and maximum 62 digits.

CODE LENGTH SETTING PROCESS




Code 93 maximum length setting



Code 93 minimum length setting


To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Save setting to confirm

Data Redundant Check


The option allows you to set decoder data redundant check before it is accepted as a good read. A higher data redundant check read setting offers more assurance that a barcode has been read correctly while a lower setting allows faster scanning performance.

Code 39 data redundant check = 0




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Code 39 data redundant check = 1




Code 93 data redundant check = 2



To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Code 93 data redundant check = 3




GS1 Databar Parameters Setting


NOTE:

- 1. There are 7 types of barcodes in the GS1 DataBar family and they are categorized into three groups in this programming guide. Barcode types in the same group use the same barcodes for setting
- 2. Before start, contact your distributor to make sure if your model and firmware version support GS1 DataBar.


Group	Representative	Contents
Group 1	GS1 DataBar Omnidirectional (Formally RSS-14)	GS1 DataBar Omnidirectional GS1 DataBar Truncated GS1 DataBar Stacked GS1 DataBar Stacked Omnidirectional
Group 2	GS1 DataBar Limited (Formally RSS Limited)	GS1 DataBar Limited
Group 3	GS1 DataBar Expanded (Formally RSS Expanded)	GS1 DataBar Expanded GS1 DataBar Expanded Stacked


GS1 DataBar Omnidirectional enable




GS1 DataBar Omnidirectional disable


To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

GS1 DataBar Limited enable


GS1 DataBar Limited disable

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


GS1 DataBar Expanded enable

GS1 DataBar Expanded disable

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


Transmit GS1 DataBar Omnidirectional check digit


Do not transmit GS1 DataBar Omnidirectional check digit




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Transmit GS1 DataBar application ID (01)



Do not transmit GS1 DataBar application ID (01)

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


GS1 DataBar Omnidirectional/EAN-128 emulation enable (JC1)


GS1 DataBar Omnidirectional/EAN-128 emulation disable (]C1)




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Transmit GS1 DataBar Limited check digit




Do not transmit GS1 DataBar Limited check digit

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


Transmit GS1 DataBar Limited application ID (01)

Do not transmit GS1 DataBar Limited application ID (01)




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Transit GS1 DataBar Expanded check digit





Do not transmit GS1 DataBar Expanded check digit




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Enable transmit AI(01) of expanded




Disable transmit AI(01) of expanded

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


GS1 DataBar Expanded/EAN-128 emulation enable (JC1)

GS1 DataBar Expanded/EAN-128 emulation disable (JC1)




Full ASCII Code Table

Full ASCII --- NUL




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

**Full ASCII ---- SOH
(Function Key---Ins)**




**Full ASCII ----STX
(Function Key---Del)**




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

**Full ASCII ---- ETX
(Function Key---Home)**




**Full ASCII ---- EOT
(Function Key---End)**




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

**Full ASCII ---- ENQ
(Function Key---Up arrow)**




**Full ASCII ---- ACK
(Function Key---Down arrow)**




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

**Full ASCII ---- BEL
(Function Key---Left arrow)**




**Full ASCII ---- BS
(Function Key---Backspace)**




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

**Full ASCII ---- HT
(Function Key---Tab)**




**Full ASCII ---- LF
(Function Key---Enter(num))**




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

**Full ASCII ---- VT
(Function Key---Right arrow)**




**Full ASCII ---- FF
(Function Key---PgUp)**




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

**Full ASCII ---- CR
(Function Key---Enter(alphabet))**




**Full ASCII ---- SO
(Function Key---PgDn)**




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

**Full ASCII ---- SI
(Function Key---Shift)**




**Full ASCII ---- DLE
(Function Key---5(num))**




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

**Full ASCII ---- DC1
(Function Key---F1)**




**Full ASCII ---- DC2
(Function Key---F2)**




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

**Full ASCII ---- DC3
(Function Key---F3)**




**Full ASCII ---- DC4
(Function Key---F4)**




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

**Full ASCII ---- NAK
(Function Key---F5)**




**Full ASCII ---- SYN
(Function Key---F6)**




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

**Full ASCII ---- ETB
(Function Key---F7)**




**Full ASCII ---- CAN
(Function Key---F8)**




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

**Full ASCII ---- EN
(Function Key---F9)**




**Full ASCII ---- SUB
(Function Key---F10)**




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

**Full ASCII ---- ESC
(Function Key---F11)**




**Full ASCII ---- FS
(Function Key---F12)**




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

**Full ASCII ---- GS
(Function Key---ESC)**




**Full ASCII ---- RS
(Function Key---Ctl(L))**




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

**Full ASCII ---- US
(Function Key---Alt(L))**




Full ASCII ---- SP




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Full ASCII ---- !




Full ASCII ---- “




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Full ASCII ---- #




Full ASCII ---- \$




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Full ASCII ---- %




Full ASCII ---- &




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Full ASCII ---- ‘




Full ASCII ---- (




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Full ASCII ----)




Full ASCII ---- *




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Full ASCII ---- +




Full ASCII ----,




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Full ASCII ---- -





Full ASCII ---- .




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


Full ASCII ---- /




Full ASCII ---- 0


To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Full ASCII ---- 1


Full ASCII ---- 2

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


Full ASCII ---- 3

Full ASCII ---- 4

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


Full ASCII ---- 5


Full ASCII ---- 6




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Full ASCII ---- 7




Full ASCII ---- 8

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


Full ASCII ----9

Full ASCII ---- :




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Full ASCII ---- ;




Full ASCII ---- <




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Full ASCII ---- =




Full ASCII ---- >




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Full ASCII ---- ?




Full ASCII ---- @




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Full ASCII ---- A





Full ASCII ---- B




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Full ASCII ---- C




Full ASCII ---- D

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


Full ASCII ---- E

Full ASCII ---- F




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Full ASCII ---- G





Full ASCII ---- H




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


Full ASCII ---- I




Full ASCII ---- J

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


Full ASCII ---- K

Full ASCII ---- L

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


Full ASCII ---- M

Full ASCII ---- N




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Full ASCII ---- O




Full ASCII ---- P




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Full ASCII ---- Q





Full ASCII ---- R




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Full ASCII ---- S




Full ASCII ---- T

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


Full ASCII ---- U


Full ASCII ---- V




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Full ASCII ---- W




Full ASCII ---- X

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


Full ASCII ---- Y

Full ASCII ---- Z




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Full ASCII ---- [




Full ASCII ---- \




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Full ASCII ----]




Full ASCII ---- ^




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Full ASCII ----




Full ASCII ---- `




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Full ASCII ---- a





Full ASCII ---- b




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Full ASCII ---- c




Full ASCII ---- d

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


Full ASCII ---- e

Full ASCII ---- f




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Full ASCII ---- g




Full ASCII ---- h




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Full ASCII ---- i




Full ASCII ---- j




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Full ASCII ---- k




Full ASCII ---- l




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Full ASCII ---- m




Full ASCII ---- n




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Full ASCII ---- o




Full ASCII ---- p




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Full ASCII ---- q




Full ASCII ---- r




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Full ASCII ---- s




Full ASCII ---- t




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Full ASCII ---- u





Full ASCII ---- v




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Full ASCII ---- w




Full ASCII ---- x

To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.


Full ASCII ---- y

Full ASCII ---- z




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Full ASCII ---- {




Full ASCII ---- |




To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Full ASCII ---- }




Full ASCII ---- ~



To prevent confusion in code scanning, cover the unwanted label and present the desired barcodes one by one to the scanner.

Full ASCII ---- DEL



APPENDIX A

CODE 39 FULL ASCII CODE TABLE

ASCII	CODE 39	VALEUR HEXA.	ASCII	CODE 39	VALEUR HEXA.
NUL	%U	00	%	/E	25
SOH	\$A	01	&	/F	26
STX	\$B	02	'	/G	27
ETX	\$C	03	(/H	28
EOT	\$D	04)	/I	29
ENQ	\$E	05	*	/J	2A
ACK	\$F	06	+	/K	2B
BEL	\$G	07	,	/L	2C
BS	\$H	08	-	-	2D
HT	\$I	09	.	.	2E
LF	\$J	0A	/	/	2F
VT	\$K	0B	0	0	30
FF	\$L	0C	1	1	31
CR	\$M	0D	2	2	32
SO	\$N	0E	3	3	33
SI	\$O	0F	4	4	34
DLE	\$P	10	5	5	35
DC1	\$Q	11	6	6	36
DC2	\$R	12	7	7	37
DC3	\$S	13	8	8	38
DC4	\$T	14	9	9	39
NAK	\$U	15	:	/Z	3A
SYN	\$V	16	;	%F	3B
ETB	\$W	17	<	%G	3C
CAN	\$X	18	=	%H	3D
EM	\$Y	19	>	%I	3E
SUB	\$Z	1A	?	%J	3F
ESC	%A	1B	@	%V	40
FS	%B	1C	A	A	41
GS	%C	1D	B	B	42
RS	%D	1E	C	C	43
US	%E	1F	D	D	44
SP	SP	20	E	E	45
!	/A	21	F	F	46
"	/B	22	G	G	47

#	/C	23		H	H	48
\$	/D	24		I	I	49

ASCII	CODE 39	VALEUR HEXA.		ASCII	CODE 39	VALEUR HEXA.
J	J	4A		e	+E	65
K	K	4B		f	+F	66
L	L	4C		g	+G	67
M	M	4D		h	+H	68
N	N	4E		i	+I	69
O	O	4F		j	+J	6A
P	P	50		k	+K	6B
Q	Q	51		l	+L	6C
R	R	52		m	+M	6D
S	S	53		n	+N	6E
T	T	54		o	+O	6F
U	U	55		p	+P	70
V	V	56		q	+Q	71
W	W	57		r	+R	72
X	X	58		s	+S	73
Y	Y	59		t	+T	74
Z	Z	5A		u	+U	75
[%K	5B		v	+V	76
\	%L	5C		w	+W	77
]	%M	5D		x	+X	78
^	%N	5E		y	+Y	79
_	%O	5F		z	+Z	7A
`	%W	60		{	%P	7B
a	+A	61			%Q	7C
b	+B	62		}	%R	7D
c	+C	63		~	%S	7E
d	+D	64		DEL	%T	7F

APPENDIX B

FUNCTION KEY EMULATION

FUNCTION KEY	ASCII	CODE 39	FUNCTION KEY	ASCII	CODE 39
Ins	\$A	01	F1	\$Q	11
Del	\$B	02	F2	\$R	12
Home	\$C	03	F3	\$S	13
End	\$D	04	F4	\$T	14
Up	\$E	05	F5	\$U	15
Down	\$F	06	F6	\$V	16
Left	\$G	07	F7	\$W	17
Backspace	\$H	08	F8	\$X	18
TAB	\$I	09	F9	\$Y	19
Enter(num)	\$J	0A	F10	\$Z	1A
Right	\$K	0B	F11	%A	1B
PgUp	\$L	0C	F12	%B	1C
Enter	\$M	0D	ESC	%C	1D
PgDn	\$N	0E	Ctl(L)	%D	1E
shift	\$O	0F	Alt(L)	%E	1F
5 (num)	\$P	10			

Enter/Exit programming

